

1) How do I get started with my GPS?

Answer:

- a) Please charge battery for a full 8 hours before use
- b) Make sure the power switch is “on”. It is located on the right side of GPS (please refer to the user’s manual for more details)
- c) Please note that the Maps are already on the GPS (NO SD Card required)
- d) Press Navigation
- e) Follow the prompts

2) Why won’t my GPS turn on?

Answer:

- a) Make sure the On/Off switch is turned to “ON” (to locate the on/off switch, please refer to pg. 5 in the manual)
- b) Make sure the unit is charged for a full 8 hours before use
- c) After completing the above steps, make sure you press and hold Hibernate/Wake Up power button for at least 3 seconds. (to locate, please refer to the manual)

3) How do I charge the battery?

Answer:

- a) You can charge the GPS unit by:
 - i. The USB port on your computer: You were provided a USB cable with your unit, plug the cord in the USB port on the GPS, then connect it to the computer’s USB port. For more information on where the USB port is located on your GPS, please refer to the manual.
 - ii. The car charger provided in your GPS box. To locate the power jack on your GPS, please refer to the manual. We recommend that you keep the GPS plugged in the car adapter while driving to preserve battery life.
 - iii. A home charger is also available for purchase through this link- http://www.invionusa.com/products_accessories.html. We recommend that you do not purchase a charger from other manufacturers as it may not be compatible with the GPS and may damage the unit. If any damage occurs, please note that it will NOT be covered under warranty.

4) Why does the GPS voice mispronounce some street names?

Answer:

- a) It is a computerized/synthesized voice that is programmed to pronounce the words phonetically, or exactly as it’s spelled on the screen; it may not always pronounce the street names as you do.

5) The keys on the touch screen are too small and I have trouble entering information.

Answer:

- a) For easier input, please use the stylus that is included on your unit. It is located on the BACK of the unit, in the bottom left hand corner; to retrieve just slide it out to the left.

6) Why does my unit have a SD or Micro SD Card slot?

Answer:

- a) Your unit is fully functional, and the maps are loaded on the internal memory (no need for a SD Card). However, the SD Slot is provided for any future map updates, as new maps become available. Please visit www.naviextras.com to purchase additional map content

8) How do I update my maps? How often are they updated?

Answer:

- a) You can purchase additional map content at www.naviextras.com

9) How do I use my mounting bracket?

Answer:

- a) Place the GPS into the bracket (make sure the tab is on the top)



- b) Then lock into place by pulling tab forward



- c) Make sure the 3 tabs on the back of the bracket are in the same position as the 3 tabs on the windshield mount (2 sides and 1 bottom tab)



d) Next, attach the mounting bracket by sliding it downward onto the windshield mount and locking into place.



INVION

10) How do I attach the windshield mount to the window?

Answer:

- b) For best results, please make sure the area on the window is clean first. Press the suction cup on the windshield firmly and push the tab to lock in place (see picture below). Check to make sure it's secure in place. Please note that in some states, such as California, it is **ILLEGAL** to attach your GPS to the windshield. Please check with your state laws. To comply with these laws, we offer a GPS Cushion that will allow you to place it on your dashboard safely and securely. The GPS CUSHION is available for purchase at http://www.invionusa.com/products_accessories.html



11) Why is my street address not showing up on the map?

Answer:

a) Maps are generally updated yearly. Please check first to see if you typed in the correct and valid address. If it still is not found, it may be a street or address that has not yet been added to the map directory.

12) Why is it taking a long time to acquire a signal or why is my signal too weak?

Answer:

a) There are many factors that may affect your GPS satellite signal such as: The weather (if it's too cloudy, etc.. your GPS may experience difficulty in acquiring a signal; you may be in a remote area where there are no reliable satellite signals available; you don't have a clear view of the sky, etc.

13) The GPS screen froze. What do I do?

Answer:

- a) Turn GPS off by holding the Hibernate power button down for 3 seconds. Wait 1 minute and turn it back on by holding the button again for 3 seconds.
- b) If that does not work, you can restart it by pushing the reset button with the stylus end. For more info on locating the reset button, please refer the manual. *Please note that if you use this method, it will ERASE all previously saved information, and will it restore it back to Factory settings. We are not responsible for any lost information.

14) Why is the GPS taking me on a different route than I normally travel on?

Answer:

a) You can set different route settings in the Manage Route setting on the GPS. For more information on these settings please refer to the manual.

15) Why is my screen too hard to read?

Answer:

a) LCD screens in general can be difficult to see in the sunlight. Avoid placing the screen in direct sunlight. Also make sure that the GPS is in day mode during the daytime, and night mode during evening, for easier viewing. You can do this manually or you can set your GPS to automatically switch between day and night modes. For more information, please refer to page 10 in the manual.

16) How do I use the POI (Points of Interests) Option?

Answer:

a) You can search the list of POI's either by category or by the specific name of what you are looking for; there are approximately millions POI's to choose from. To learn more about searching POI's with those options, please refer to the manual.